



musik. kritik. les connaisseurs

[www.raus-aus-der-prostitution.de](http://www.raus-aus-der-prostitution.de)

## Native Instruments **Traktor Pro**

Midi Mapping

for

## **Hercules DJ Console MK2**

This document describes the Midi Mapping functionalities for Native Instruments Traktor Pro (Version 1.01) for the **Hercules DJ Console MK2** MIDI controller included in the .tsi file.


The .tsi file was created based on the original NI Traktor Pro file. However we felt some things were missing. In comparison to the .tsi-file included in Traktor Pro, our adaption covers a new „Shift-Mode“ for the 1,2,3 keys similar to the official Hercules .tki-File for Traktor 3 aswell as some enhancements to the FX, Loop and Cue modes.

The instructioun only covers the added „shift“ functions aswell as the FX / Loop / Cue modes. The standard functions are more or less self explanatory.

To load the .tsi-file, go to PREFERENCES and select IMPORT in Traktor Pro.

 Connaisseur\_M , december 2008.

# Traktor Pro - Midi Mapping for Hercules DJ Console MK2




## „Shift mode“ (no LEDs on)

When no FX/Cue/Loop mode is selected (no LED), the buttons 1 – 3 have these special functions while holding them:

### Button 1 hold

- + Jogwheel LEFT (A) = Headphone Mix
- + Jogwheel RIGHT (A) = Headphone Vol.
- + Pitch knob (B) = Pitch Fader **fast adjust**
- + Autobeat (C) = Tap Tempo


### Button 2 hold

- + Jogwheel (A) = Gain
- + Pitch knob (B) = Filter knob
- + Pitch Bend „+“ (D)  = Filter on/off

### Button 3 hold

- + Jogwheel (A) = Scratch (& Scratch On)
- + Pitch knob (B) = Key knob


# Traktor Pro - Midi Mapping for Hercules DJ Console MK2





## FX-Mode (FX LED = on):

- Button „1“ hold = FX1 Switch on/off
- Button „1“ hold + Jogwheel (A)= FX1 Amount
- Button „2“ hold = FX2 Switch on/off
- Button „2“ hold + Jogwheel (A)= FX2 Amount
- Button „3“ hold = FX3 Switch on/off
- Button „3“ hold + Jogwheel (A)= FX3 Amount


## Deck A

- Prev.-Button „|<“ (C) = FX1 Select FX (Deck A)
- Next-Button „>|“ (C) = FX2 Select FX (Deck A)
- Pitch Bend „-“ (C) = FX3 Select FX (Deck A)
- Pitch Bend „+“ (D)  = FX Unit 1 on/off (Deck A)

## Deck B

- Pitch Bend „-“ (D)  = FX Unit 2 on/off (Deck B)
- Pitch Bend „+“ (C)  = FX1 Select FX (Deck B)
- Prev.-Button „|<“ (C) = FX2 Select FX (Deck B)
- Next-Button „>|“ (C) = FX3 Select FX (Deck B)


# Traktor Pro - Midi Mapping for Hercules DJ Console MK2



## Cue-Mode (Cue LED = on):

- Buttons ① ② ③ (A) = Select Hotcue 1/2/3
- Pitch Bend (-) (+) (B) = Prev / Next Cue / Loop
- CUE Button (C) = Cue Set & Store
- Prev.-Button (D) = Delete Cue / Loop

# Traktor Pro - Midi Mapping for Hercules DJ Console MK2



## **Loop-Mode (Loop LED = on):**

- Pitch Bend (-, +) & 1 2 3 = Set Loop + Size (8 / 4 / 2 / 1 / 1/2)